



User Manual

Rev. October 2009


the.hot.mix
vidio

Main screen



- A) Skip Song – Use this button to skip the current song playing
- B) Play Playlists – Use this button to go to Choose Playlists to play
- C) DJ Cue – Use this button to go to the DJ Cue to play songs or manage the existing cue
- D) Edit Playlists – Use this button to go to Edit Playlists to create, edit, or delete an existing playlist
- E) Time Remaining – This displays how much time is left on the current song playing
- F) Song Rating – This displays the rating for the currently playing song, you can also re-rate the song by clicking on a star
- G) Song Title – This displays the song title, remix, artist, featuring artist, and what playlist the song was chosen from

Edit Playlists




- A) Add Button – Use this button to add a new playlist
- B) Delete Button – Use this button to delete the selected playlist, you will be asked to confirm before deleting
- C) Edit Button – Use this button to edit the selected playlist
- D) List of Playlists – This shows the list of all your custom playlists

Editing a playlist



- A) Title – Shows the name of the playlist you are editing
- B) Change Name – Change the name of the playlist
- C) Keyboard – Use this button to open the on-screen keyboard
- D) Import – Use this button to import songs from playlists or auto-generated playlists
- E) Shuffle – This mixes up the songs in the playlist, this has no function as when the playlist is played, the songs are picked at random.
- F) Clear playlist – Use this button to remove all songs from the playlist, you will have to confirm before songs are removed
- G) Search – Use this text area to search for songs in the system
- H) Sort – Use the Artist or Song sort option
- I) Songs picked – This is the list of songs that you have picked for the playlist – You can also re-order by dragging songs
- J) Playlist selector – Use this to select between all songs or other playlists on the system
- K) Add to picked songs – Use this button to add the selected song to the playlist
- L) Remove from playlist – Use this button to remove the selected song from the playlist
 - a. Alternatively to K and L, you can drag-n-drop the songs between the list.
- M) Available songs – This is the list of songs that are available to pick from, this can change depending on what playlist you have selected from the Playlist selector (J)
- N) Save – Use this button to save playlist changes

Playlist Playlists



- A) Pre-programmed playlists – This is the list of playlists that came with the system and are updated regularly
- B) Selected playlists – This is the list of playlists that you have selected to play
- C) Add playlist to selected – Use this button to add the selected pre-programmed or custom playlist to the selected list
- D) Remove playlist from selected – Use this button to remove the selected playlist from the selected list
- E) How many plays per playlist – Use this option to select how many songs you want to play per playlist before it moves to the next playlist in the list
- F) How long to play these playlists – Use this option to select how long to play these playlists before reverting back to the pre-programmed playlist schedule
- G) Normal or Shuffle playback
 - a. Normal – Use this option to play back the playlists from top down
 - b. Shuffle – Use this option to randomly select which playlist the next song is picked from
- H) Custom playlists – This is the list of playlists that you have created for the system
- I) Play Now – Use this button to play the selected playlists immediately
- J) Play Next – Use this button to wait for the current song to play then begin playing these playlists

DJ Cue



- A) Search – Use this text area to search for songs on the system
- B) Sort – Use the Artist or Song sort to sort the available songs list
- C) Import – Use this button to import songs from playlists or other auto-generated playlists
- D) Shuffle – Use this button to mix up the songs that are in the picked list
- E) Clear – Use this button to clear the songs that are in the picked list
- F) Picked list – This list shows the songs that you’ve picked
- G) Playlist selector – Use this to select between auto-generated lists or pre-programmed playlists
- H) Add to DJ Cue – Use this button to add the selected song to the DJ Cue
- I) Remove from DJ Cue – Use this button to remove the selected song from the DJ Cue
- J) Available songs – This list shows what songs are available to choose from
- K) Save – Use this button to save the changes to the DJ Cue and return to the previous screen